

## DRIVING MECHANISM

## BASE & CUTTING GUIDE

## SHARPENING

### DRIVING MECHANISM

R1700..... Worm Wheel 1/6  
M0508..... Stepped Screw  
R0554..... Knob Screw  
R0564..... Spacer  
R0566..... Nut  
R0568..... Flat Head Screw  
R0572..... Flat Head Screw  
R0579..... Set Screw  
R1543..... Tapping Screw  
R0580A..... Knife Lock Nut  
R0624..... Stepped Shaft  
R0626A..... Grease Bolt  
R0630C..... Bushing

M0652..... Ball Bearing  
M0656..... Snap Ring  
R1500AZ..... Gear Housing  
R1504..... Knife Guard  
R1512..... Round Knife (100mm dia.)  
R1516A..... Allen Screw  
R1605..... Guard pin  
H0252..... Toothed Washer

### SHARPENING MECHANISM

M0510..... Flat Head Screw  
M0528..... Push Button  
M0602..... Stepped Shaft  
M0620..... Spring  
R0688Z..... Sharpening Stone


### BASE & CUTTING GUIDE

S0047..... Flat Head Screw  
R0432B..... Base  
M0548..... Fillister Head Screw  
R1557..... Bolt (long) M4×0.7  
R1558..... Bolt (short) M4×0.7


R0574..... Set Scr  
R0746..... Plate  
L1502A..... Cutting  
R1508..... Counte  
R0585..... Needle  
R0584A..... Shaft  
R0622A..... Roller  
R0683..... Needl  
M0690..... Wash  
R0587..... Needle  
R0586A..... Shaft  
R0622A..... Roller  
R0683..... Needl  
M0690..... Wash




## MECHANISM



## MOTOR PARTS



## ACCESSORIES



R0689..... Coller

### MOTOR PARTS

R1510AS.... Motor Complete (110V)  
 R1511AS.... Motor Complete (230V)  
 R1541..... Cord (110V)  
 R1542..... Cord (230V)  
 R1524..... Brush Cap  
 R1525..... Carbon Brush  
 R1526P..... Instant ON/OFF Switch  
 R1531A..... Cord Holder  
 R1510RS.... Rotor Only (110V)  
 R1511RS.... Rotor Only (230V)

M0722..... Undulated Washer  
 M0724..... Washer  
 R3521..... Shaft  
 R3545..... Ball Bearing  
 R3523A..... Spacer  
 R3525..... Inverted Ring  
 R3544..... Snap Ring  
 R1658..... Spring Pin  
 R1750..... Worm 1/6  
 R1521A..... Name Plate

### ACCESSORIES

R0628..... Allen Key (1.5mm)  
 R0798..... Spanner  
 R1515..... 8-Sided Knife